

First Time Set-Up Instructions



Take a new Drain Insert and place it in the waste trap.



Press down on the drain insert until you feel and hear a slight popping sound. The insert must be tight.



Pour about 1 litre of water over the Drain Insert. Then slowly pour the **entire contents of the Odour Barrier** onto the Drain Insert.. Wipe clean. The ZeroFlush Urinal is now ready for use.



Daily Cleaning Instructions



Remove debris.



Spray and wipe down



Wipe clean.

For replacement kits contact:-

BRIGHTWATER Environmental Ltd,
Redborough Barn,
Stalisfield Green
Faversham,
Kent ME13 0HX

T 01795 890590
F 01795 890292
E sales@bwater.eu
W www.bwater.eu